



Model # PB KPIC4____


SAFETY WARNINGS & EQUIPMENT INSPECTION

- Owners and installers please note these safety warnings and make use of this checklist on a regular basis.
- Follow installation instructions when erecting equipment.
- Ground surfaces around equipment should be restored as needed. Concrete footings should never be exposed. Surface depth should comply with ASTM and CPSC specifications.
- Check for and repair damage caused by wear or vandalism, a major factor in injury causing situations.
- All protruding bolts should be covered or cut off and finished smooth. Sharp edges on pipes should be capped or removed. Check for bent, broken, or severely worn pipe, and replace.
- All equipment should be free of rust and repainted whenever necessary to deter rusting.
- We provide our customers with layout sheets and installation instructions. Please keep on file the specifications sheet that contains the listing of every part used.
- Never add components not intended for use with this product.
- Regular maintenance is necessary in this and all park and recreational equipment to insure the safety of the user.
- Note: Proper maintenance of equipment requires regular tightening of all bolts, nuts, and setscrews.
- Note: Regular checking of all parts, castings, etc. should be made. If a part is broken or worn, it should be replaced immediately.
- Check to be sure all fittings are tight and that bars and pipes do not move.
- Frog Furnishings products are durable and designed to last a lifetime, like most things that spend the majority of time outdoors, sometimes they need a little cleaning. In most cases, all a Frog product requires is mild dish soap, a bucket of warm water and a clean cloth. Apply the soapy mixture to scrub away the dirt and then rinse with water. If you have some stubborn dirt down in the grooves and divots, mix 1 part bleach to 2 parts water, apply with your clean cloth, scrub with a soft bristle brush if needed and then rinse.


HARDWARE




1/4" x 3 1/2"
Hex Lag Bolt



#8 x 3"
Wood Screw




#7 x 2.5" T-25
Torx Flat Head Screw



1/4" Flat Washer


TOOLS REQUIRED




7/16" Wrench




7/16" Socket Wrench




Tape Measure



Level



Drill & Philips Head Drill Bit



Torx Head Wrenches/Bits

PRODUCT SPECIFICATIONS

PB KPIC4 4' KIDS TABLE

Seats: 2" x 4" Recycled Plastic.


Top: 1/2" HDPE.

Legs: A-Frame is made up of 2" x 6" Recycled Plastic. Supports are made up of 2" x 4" Recycled Plastic.

Hardware: Stainless Steel fasteners.




Dimensions: Top is 24" wide x 48" long and is 21" high. Seats are 6-3/8" wide x 48" long and 11" high.
Outside to outside dimension is 42" x 48".

COMPONENTS





ITEM NO.	PartNo	DESCRIPTION	Qty.
1	-	kids table A frame	2
2	PL 3017 (37-1/2" long)	kids table top support	2
3	RPS 1095	RPS 1095 kids table top	1
4	PL 8001	4' 2x4 bench plank	4
5	RMO 5000	1/4" flat washer SS	8
6	RMO 5007	1/4" x 3-1/2" lag bolt, SS	8
7	RMO 5366	#7 x 2-1/2" long T-25 torx flat head screw	12
8	RMO 5355	#8 x 3" wood screw	8

STEP 1



Attach the supports to the A Frame using the specified hardware and dimensions.



STEP 2



NOTE: Seat Plank to be flush with outer edge of the A Frame

Center the Seat Planks on the A Frames using the pre drilled holes, install using the specified hardware.

STEP 3



Place the Table Top on the bases, the top will overhang each base end by 3 3/4" and 1 3/8" on the sides, attach using specified hardware.

OVERALL DIMENSIONS

